




NOTE:
DISCONNECT OEM DASH AIR CLUTCH WIRE WHE
WIRING(C/SYSTEM/LESSWIRING(MAXSYSTEM))



CIRCUITBREAKER IDENTIFICATION

- TYPE II MANUAL RESET SWITCH WHEN EXTERNAL BUTTON IS PUSHED.
- TYPE B - RESET WHEN OVERCURRENT CORRECTED OR REMOVED.

TOLERANCES		SCALE	
DECIMAL		AS SHOWN	
RAC SYSTEMS		DRAWN BY	
WIRING DIAGRAM RAC-2025 TI-E-IN		DATE	
REVISED		DRAWING NUMBER	
		RAC-2025	