




NOTE:  
DISCONNECT OEM DASH AIR CLUTCH WIRE WHE  
WIRING/C/SYSTEMS(UNLESS WIRING MAX SYSTEM)



**CIRCUIT BREAKER IDENTIFICATION**

- TYPE II MANUAL RESET RESET WHEN EXTERNAL BUTTON IS PUSHED.
- TYPE I - RESET WHEN OVERCURRENT CORRECTED OR REMOVED.

FOR PARTS:	SCALE:	DRAWN BY:
REVISION:		APPROVED BY:
FRACTIONAL:	RAC SYSTEMS	
JOB:	RAC-2222	
DATE:	RAC-2222	
APPROVAL:	RAC-2222	