




NOTE:  
DISCONNECT OEM DASH AIR CLUTCH WIRE WHEN WIRING/AC SYSTEM (UNLESS WIRING MAX SYSTEM)



**CIRCUIT BREAKER IDENTIFICATION**

- TYPE II MANUAL RESET RESET WHEN EXTERNAL BUTTON IS PUSHED.
- TYPE I - RESET WHEN OVERCURRENT CORRECTED OR REMOVED.

TOOL SERVICES	SCALE	DRAWN BY
ORDINAL		APPROVED BY
<b>RAC SYSTEMS</b>		
FRACTIONAL	JOS	RAC-2929
ABSOLUTE	DATE	ORDER NUMBER
		RAC-2929